



## JUNGLE KIT ZEBRA

### Technical Sheet

**NAME:**

**TYPE:**

**TECHNICAL DATA:**

**JUNGLE KIT ZEBRA**

water-based interior coating

**specific weight:** **PRIMER 700 AVORIO 10:**  $1.380 \pm 30$  gr/LT at 25°C

**MZ 600 TRASPARENTE:**  $1.025 \pm 30$  gr/LT at 25°C

**ZE 611:**  $1.460 \pm 30$  gr/LT at 25°C

**ZE 612:**  $1.420 \pm 30$  gr/LT at 25°C

**VALFLOK 300 TRASPARENTE:**  $1.010 \pm 30$  gr/LT at 25°C

**yeild:** 3 and 10 m<sup>2</sup> (it may vary according to the roughness, porosity and surface absorption and to the method of application)

**colours:** colours from the catalogue

**packaging:** 3 and 10 Mq

**on the surface:** 1 hours at 20°C

**overpainting:** 3 - 4 hours at 20°C

**below the surface:** 24 hours at 20°C

**DRYING:**

**CHARACTERISTICS AND RESISTANCE:**

JUNGLE KIT ZEBRA comprises a series of liquid and creamy water-based decorative paints for interiors that offer unique visual effects of extraordinary beauty.

After its complete hardening and drying a breathing film forms with a good resistance to bumps and standard 15 days after its application cycle the surfaces achieves its definitive qualities so it become breathable, resistant to washings with water and common neuter detergents.

**PREPARATION OF THE SURFACE :**

JUNGLE KIT ZEBRA can be applied to various surfaces including cement (new or old), plasterboard, plaster of Paris, wood (new or old), plastic, glass and iron (new or old), provided they are free of humidity, well dry, smooth and have already been treated.

Any loose or dusty paint, as well as any grease or rust, must be removed and the surface washed with suitable soap. Fill the surfaces to be decorated, if necessary, and apply a base coat that is suitable to the type of surface to be treated.

Once the base coat is dry, apply the products in the Kit as indicated

**PREPARATION OF THE PRODUCT :**

**dilution:** all the products in the JUNGLE KIT ZEBRA are ready to use and must be carefully mixed before and during the application.

**APPLICATION CYCLE:**

**1) PRIMER 700 IVORY 10.** (Coverage 0.080 l/sqm) Apply a coat using a wool roller. Allow to dry for 4 hours at 20°C, then proceed to Point 2.

**2) MZ 600 TRANSPARENT.** (Coverage 0.140 l/sqm) Apply two coats using a wool roller. Allow to dry for approx. 2 hours at 20°C before applying the second coat. Add the second coat of MZ 600 TRANSPARENT and allow to dry for 2 hours at 20°C then proceed to Point 3.



SC 00211

**3) ZE 611 already coloured.** (Coverage 0.100 l/sqm) Apply a thick coat of paint with the 20 cm wool roller over the entire surface to be treated; avoid joints from forming and do not retouch the decorated surface even if still wet. Allow to dry for approx. 2 hours at 20°C, then proceed to Point 4.

**4) MZ 600 TRANSPARENT.** (Coverage 0.140 l/sqm) Apply two coats using a wool roller. Allow to dry for about 2 hours at 20°C before applying the second coat. Add the second coat of MZ 600 and allow to dry for 2 hours at 20°C, then proceed to Point 5.

**5)** Position the **ZE 6F STENCILS** and align the connection points between the various stencils. The stencils must be fixed in vertical strips starting from the top left end and moving towards the bottom end. Use a pencil to mark the points when repositioning the successive stencils (Point 7). These marks may be removed with a rubber once work is completed. Once the first strip of stencils has been placed, proceed to Point 6.

**6) ZE 612 already coloured.** (Coverage 0.120 l/sqm) Apply a coat of paint with the 10 cm wool roller over the entire surface covered with the **ZE 6F STENCILS**. Remove the stencils and allow to dry for approx. 10 minutes at 20°C before proceeding to Point 7.

**7)** Clean the **ZE 6F STENCILS** already used and reposition them by aligning the points to form another strip alongside the one already formed. Once the second strip of stencils has been positioned, proceed to Point 8.

**8) ZE 612 already coloured.** (Coverage 0.120 l/sqm) Apply a coat of paint with the 10 cm wool roller over the entire surface covered with the **ZE 6F STENCILS**. Remove the stencils and allow to dry for about 10 minutes at 20°C before repeating Points 5, 6, 7 and 8 on the rest of the surface to be decorated. Proceed to Point 9.

**9) VALFLOK 300 TRANSPARENT.** (Coverage 0.200 l/sqm) Apply two coats to the entire surface with the wool roller. Allow to dry for approx. 1 hour at 20°C before applying the second coat.

**N.B.:** All the above-mentioned phases must be completed without interruptions once they are started, while any areas that have already been coated must not be retouched.

The **ZE 6F STENCIL** must be repositioned several times and may lose its adhesive properties. If such is the case, spray the side of the stencil to be fixed to the surface with ADIPIT 500 PV 73 temporary spray that comes with the JUNGLE KIT.

**Stability:** approximately 2 years.

**NOTES:**

Application temperature must be between +5°C and +30°C. Wash the tools soon after use with use.

Technical Sheet n° SC 00211 issued by the Responsible Control Department

Edition n° 1

April 2009